



MAINTENANCE & CLEANING instructions

Product: StrandTec

- Interior space conditions must be maintained with a relative humidity ranging from 25% to 55%. Temperature range must be maintained between 55° to 80° Fahrenheit.
- Accumulation of dust and dirt are best removed with a soft brush attachment on a vacuum cleaner. Use vacuum attachments with at least 1" soft bristle brushes.